

ECONirman

Whole Building Performance

USER MANUAL

September 2011

ECONirman Whole Building Performance

USER MANUAL

Developed by:
USAID ECO-III Project
International Resources Group
2 Balbir Saxena Marg, Hauz Khas, New Delhi, India

Project Guidance

USAID/India
Archana Walia

Bureau of Energy Efficiency

Ajay Mathur
Sanjay Seth
Shabnam Bassi
Girja Shankar
Brijesh Manan

Development Team

International Resources
Group, USAID ECO-III
Project

Aalok Deshmukh
Sanyogita Manu
Bibhash Das
Harshitha Raju
Satish Kumar

The Weidt Group, Inc. (Software Design)

Prasad Vaidya
John Melchert
Vinay Ghatti
Phil Davis
Chris Oace
Paul Welter
Dave Killion
John Cherba
Chris Baker
Claire Stenroos
Mark Bergass
Michele Smeaton
Alex Fritz

Supporting Partners




Technical Consultants

Vikas Arora
Shruti Narayan
Lata Iyer

The development of ECONirman Whole Building Performance Tool and this User Manual are made possible by the support of the American People through United States Agency for International Development (USAID) under the terms of Award No. 386C-00-06-00153-00. Both are the sole responsibility of International Resources Group and do not necessarily reflect the views of USAID or the United States Government.

How to use this manual

The following symbols and icons are used in this user manual:

Symbol/Icon	Description
§	Section of the user manual
*	Mandatory field
	External web link
	Useful tip
	Caution or warning

The text underlined in blue colour is a cross-reference within the user manual itself. In the soft copy, click it to open the section that is cross-referenced.

Table of Contents

1. Introduction	1
2. Key Concepts	2
2.1. Energy Conservation Building Code (ECBC)	2
2.1.1. ECBC Tip Sheets	2
2.2. ECBC Conformance	2
2.2.1. Mandatory Requirements	3
2.2.2. Prescriptive Method	3
2.2.3. Whole Building Performance Method.....	3
Energy Simulation Software.....	4
3. EONirman Whole Building Performance Tool	5
3.1. Modelling Protocol and Default Inputs.....	5
3.2. Salient Features.....	6
3.3. Prerequisites.....	6
4. Tool Navigation	8
4.1. How to Access.....	8
4.2. Home Page.....	9
4.3. User Account	10
4.3.1. New User.....	10
4.3.2. Log In	11
4.3.3. Retrieve Forgotten Password	11
4.3.4. Change Password and Update Profile	13
4.3.5. Log Out.....	13
5. Manage Projects.....	14
5.1. Project Actions.....	15
5.1.1. Create Project.....	15
5.1.2. Edit Project	15
5.1.3. Delete Project.....	15
5.1.4. Copy Project.....	16
5.2. Filter Project List	17
6. Project Information	18
6.1. General.....	18
6.2. Building.....	20
6.2.1. Building Shape	21
6.2.2. Building Dimensions	22

6.2.3.	Building Orientation	25
7.	Building Use	26
7.1.	Space Use	26
7.1.1.	Area Allocation	27
7.1.2.	Lighting	27
7.1.3.	Loads	28
7.1.4.	Thermal Comfort.....	30
7.1.5.	Schedules.....	31
	Season	32
	Days	33
	Schedule	33
7.2.	Zoning	35
7.2.1.	Floor Affinity	36
7.2.2.	Perimeter Allocation.....	36
8.	Envelope	38
8.1.	Windows and Walls	38
8.1.1.	Wall Construction	40
	Customized Wall Assembly	40
8.1.2.	Window Construction.....	41
	Customized Window Assembly.....	41
8.1.3.	Window Wall Ratio	42
8.1.4.	Shading	43
	Horizontal Shading	43
	Vertical Shading	44
8.2.	Roofs and Skylights	45
8.2.1.	Roof Construction.....	45
	Customized Roof Assembly.....	46
8.2.2.	Skylight Roof Ratio	47
8.2.3.	Roof Reflectivity.....	47
9.	Heating, Ventilation and Air Conditioning.....	48
9.1.	Systems.....	49
9.1.1.	Add System	50
9.1.2.	Edit System	51
	Air Systems	51
	Cooling Plant	53
	Heating Plant.....	54
9.1.3.	Delete System	55
9.2.	Assignments	55

10. Conformance Check	57
10.1. Mandatory Requirements.....	57
10.2. Simulation.....	58
10.3. Results	59
10.3.1. Interpreting the Results.....	59
Meeting the Loads	59
Energy Use and Energy Performance Intensity (EPI)	60
10.3.2. Building Conformance Report.....	61
11. Appendix A: Definitions and Acronyms	62
11.1. Definitions.....	62
11.2. List of Acronyms	68
12. Appendix B: Computer Settings	71
12.1. Web Browser	71
12.2. Conformance Reports.....	72

1. Introduction

The Ministry of Power, Government of India, under the provision of the Energy Conservation Act, 2001 launched the **Energy Conservation Building Code (ECBC)** in May 2007. Since then, the Bureau of Energy Efficiency (BEE) has been promoting the implementation of the ECBC through several capacity building programs. United States Agency for International Development (USAID) supported Energy Conservation and Commercialization - Phase-III (ECO-III) Project has been working closely with BEE on these initiatives, and has developed ECBC User Guide and [ECBC Tip Sheets](#) (§ 2.1.1) for raising awareness on the ECBC among the stakeholders.

During these capacity building efforts, a strong need was felt to assist architects and engineers at the design stage so that they are able to assess and demonstrate conformance of their proposed buildings with respect to the ECBC. It is with this objective that the development of **EONirman Whole Building Performance Tool**, an online conformance check tool, was undertaken by ECO-III Project in partnership with BEE. The tool uses the **Whole Building Performance (WBP) Method** detailed in Appendix B of the ECBC to assess conformance. It is developed by The Weidt Group, Inc. (TWGI) under the guidance of ECO-III Project.

This manual will familiarize a user with the interface of EONirman WBP Tool and walk through the step-by-step process of assessing conformance.

2. Key Concepts

Before using EONirman WBP Tool for assessing conformance of the building, it will be beneficial to understand certain energy and conformance related concepts. These are explained in the following sub-sections.



See [Appendix A: Definitions and Acronyms](#) (§ 11) for a list of definitions.

2.1. Energy Conservation Building Code (ECBC)

The Energy Conservation Building Code (ECBC) is the result of extensive work by BEE and its Committee of Experts. Its purpose is to provide minimum requirements for energy efficient design and construction of commercial buildings and their systems. It is the first step towards promoting energy efficiency in the building sector.



Refer to ECBC User Guide (International Standard Book Number 978-81-909025-3-3, BEE, New Delhi, India) to understand the ECBC better. It is available online at http://eco3.org/?file_id=1

2.1.1. ECBC Tip Sheets

The ECBC tip sheets created by ECO-III Project help in understanding the implications of the ECBC on different building components. The following four tip sheets are available for reference:

- **Energy Simulation:** http://eco3.org/?file_id=11
- **Building Envelope:** http://eco3.org/?file_id=19
- **Building Lighting Design:** http://eco3.org/?file_id=20
- **HVAC System:** http://eco3.org/?file_id=25

2.2. ECBC Conformance

The Bureau of Energy Efficiency's intention is to facilitate the design and construction of the buildings conforming with the ECBC in India. The conformance process has been made flexible enough to help designers and architects in meeting the ECBC requirements.

Conformance with the ECBC can be achieved by meeting the mandatory requirements in the ECBC, in addition to either meeting the prescriptive requirements

using the [Prescriptive Method](#) (§ 2.2.2) or meeting the requirements in the [Whole Building Performance Method](#) (§ 2.2.3).


2.2.1. Mandatory Requirements

The conformance procedure requires the building to fulfil a set of mandatory provisions related to energy use, as well as demonstrate conformance with the specified requirements stipulated for the different building components and systems.

2.2.2. Prescriptive Method

The Prescriptive Method of conformance specifies prescribed minimum energy efficiency parameters for various components and systems of the building. Conformance with the ECBC can be achieved by meeting or exceeding the specific levels described for each individual element of the building systems.



Refer to **ECONirman Prescriptive Tool User Manual** (available online at http://eetools.in/ECONirman_Prescriptive_UserManual.pdf ) to assess conformance using the Prescriptive Method.

2.2.3. Whole Building Performance Method

The Whole Building Performance (WBP) Method offers considerable design flexibility and allows for conformance with the ECBC to be achieved by optimizing the energy used by various components and systems in order to find the most effective solution. The WBP Method requires the use of an energy simulation software approved by the *Authority Having Jurisdiction* to simulate and compare energy use of the *Proposed Design* and the *Standard Design* of the building.

Appendix B of the ECBC prescribes the protocol for developing a computer-based model for the purpose of energy simulation of the *Proposed Design* and the *Standard Design* of the building. Energy consumption of the *Standard Design* is the upper limit of energy use allowed for that particular building that meets all the prescriptive requirements applicable to that building. The conformance is achieved if the energy consumption of the *Proposed Design* is no greater than the energy consumption of the *Standard Design*. The following are the basic steps involved:

- Design the building with energy efficiency measures; the prescriptive approach requirements provide a good starting point for the development of the design.
- Meet the applicable mandatory requirements of the ECBC.

- Simulate the energy use of the building using the software approved by the *Authority Having Jurisdiction*. This is to be done by following the protocol in Appendix B to simulate the *Proposed Design* and the *Standard Design*.
- Compare the simulated energy use of the *Proposed Design* and the *Standard Design*.


If the energy consumption of the *Proposed Design* is no greater than the energy consumption of the *Standard Design*, the building conforms with the ECBC.

Energy Simulation Software

The use of energy simulation software is necessary to show conformance with the ECBC using the WBP Method. Energy simulation is a *computer-based analytical process* that helps building owners and designers to evaluate the energy performance of a building before it is built and operated.

The energy simulation software can model the thermal, visual, ventilation, and other energy consuming processes taking place within the building to predict its energy performance. The software takes into account the building geometry and orientation, materials, façade design and characteristics, climate, indoor environmental conditions, occupant activities and schedules, Heating Ventilation and Air Conditioning (HVAC), lighting system, and other parameters to simulate the energy performance of the building.



Refer to **Energy Simulation** tip sheet available at http://eco3.org/?file_id=11  to learn more about building energy simulation.

3. EConirman Whole Building Performance Tool

EConirman Whole Building Performance Tool is an energy simulation software provided by BEE to assist architects and engineers in assessing the conformance of their buildings with the ECBC using the WBP Method. It is a web-based tool that is made available to the users over the Internet with minimal software requirements, building science, or simulation expertise. With minimal learning involved, a user having knowledge equivalent to that of a fifth-year architecture student with access to about one hour of HVAC engineer's time, can use the tool to demonstrate conformance with the ECBC.

A total of 1,294 city locations in India are represented in the tool. It has 46 weather files. Each city location and weather file has been assigned to the climate zone that it falls within on the basis of Geospatial Information System (GIS) mapping of the climate zones and the cities. When a city location for the building is chosen, the tool finds the closest available weather file within the same climate zone. This weather file is selected for the simulation.

The tool requires inputs about the building from the user. Based on the inputs, it runs simulation of the *Proposed Design* and the *Standard Design* as per Appendix B of the ECBC, and compares the Energy Performance Intensity (EPI) of simulation results. The results are presented after the simulation is completed. The tool also generates a report that may be submitted to the *Authority Having Jurisdiction* to demonstrate conformance with the ECBC.



Energy Performance Intensity (EPI) is defined as the annual energy consumption measured in kWh per square meter of the built-up area of the building. It is the ratio of the total energy used to the total built-up area and is expressed as kWh/m²/year.

3.1. Modelling Protocol and Default Inputs

EConirman WBP Tool follows the modelling protocol of Appendix B of the ECBC for developing the models of the *Standard Design* and the *Proposed Design*. The following logic is used:

- The details of the building are entered and the *Proposed Design* and the *Standard Design* are developed accordingly in the background as per the rules in Appendix B of the ECBC.


Example: The user selects Daytime use or 24-hours use of the building and enters insulation values of the building materials. The tool determines the insulation values for the *Standard Design* based on the usage information entered and uses the material insulation values for the *Proposed Design*.

- The tool provides the defaults for the *Proposed Design* if its details are not specified by the user. These defaults are the same as those for the *Standard Design*.



These defaults are provided across the tool for convenience only. It is important to provide actual building inputs to run the simulation correctly for assessing conformance.

3.2. Salient Features

- ECONirman WBP Tool ECONirman Prescriptive Tool indicates if the systems and sub-systems of the building are **conforming** or **not conforming** with the ECBC and also generates a conformance report that compile the data provided by the user.
- It facilitates the users in assessing if a building meets the ECBC requirements vis-à-vis the five climatic zones in India.
- It can store multiple building projects under a single user profile.
- It stores the information in a central database for future reference, review, edit, and analysis purposes.
- It keeps the information secure and confidential.
- It allows the design teams to collaborate remotely.
- It is available in the public domain (<http://econirmanwbp.eetools.in> ) for easy access to the users.

3.3. Prerequisites

The following checklist of items (specific to the building being assessed for conformance) will come in handy while using ECONirman WBP Tool:

- Total interior floor area
- Marked-up plans by space types (see [illustrations](#) in § 7.2.2)
- Floor area for each space type
- Perimeter lengths for each space type
- Lighting Power Density (LPD) values for each space type

- Space types marked as conditioned or unconditioned
- Ventilation requirements
- Mechanical equipment sizes and efficiencies
- Pump and fan static pressures
- Envelope construction assemblies (for walls, roofs, windows, and skylights) and shading

4. Tool Navigation

ECONirman WBP Tool is aesthetically designed, keeping in mind the ease of navigation for the end-user.

The tool features different tabs at the top to navigate effectively through a project. These tabs feature sub-tabs (on the left side) that act as logical sections to enter the relevant building details to run the simulation and generate the conformance report.

For each building project, the user progresses by specifying the parameters including building shape, dimensions, orientation, building use information, and details of the HVAC systems. When complete, the simulation can be invoked to view the results for both the *Standard Design* and the *Proposed Design*.

The tool allows the user to provide inputs for the simulation that do not need to be sequential. The information can be provided in the sequence preferred by the user. This makes it more intuitive and interactive. However, to get correct results, the user needs to go through all the left side sub-tabs under each top tab and provide the information relevant to the building.



Across the tool, the fields marked with an asterisk (*) are mandatory.

4.1. How to Access


Enter the link <http://econirmanwbp.eetools.in>  in the web browser's address bar to access ECONirman WBP Tool.



See [Appendix B: Computer Settings](#) (§ 12) to learn about the settings required on a user's computer before using the tool.

4.2. Home Page

The following illustration highlights the composition of ECONirman WBP Tool home page.



A	Click About to view the tool version and credits; click Help to view this user manual
B	Enter the user credentials and click Login to assess if a building and its components conform with the ECBC using the WBP Method (see § 4.3.2)
C	Click Request Login to register as a new user (see § 4.3.1)
D	Click Forgot Password? to retrieve a forgotten password (see § 4.3.3)

4.3. User Account

This section explains how to create a new user account, log into the tool, retrieve a forgotten password, update user profile, and change a password.

4.3.1. New User

Click **Request Login** on the [home page](#) to register as a new user. The **Request Login** dialog box appears.

Request Login

* **Email** irgeco3@gmail.com

* **Password** ●●●●●●●●

* **Confirm Password** ●●●●●●●●

* **Full Name** Firstname Lastname


Company Name IRG ECO-III


Job Title Architect

Industry Energy

Submit


* Required Fields Return to Login Forgot Password?


- Enter a valid e-mail address.
- Enter a desired password and confirm it.
 -  The password is case sensitive.
- Enter name and other details.
- Click **Submit** to create the user account.
- The **Projects** page opens. See § 5 to learn how to [manage projects](#).

 If an e-mail address is unavailable or invalid, a message appears at the top of the page. Enter another e-mail address.

4.3.2. Log In

For an existing user, enter the registered e-mail address and password on the [home page](#).

 The password is case sensitive.



The screenshot shows a 'Login' dialog box with a light blue background. At the top left, the title 'Login' is displayed. Below it, there are two input fields: '* Email' containing 'irgeco3@gmail.com' and '* Password' containing a series of black dots. A blue 'Login' button is positioned below the password field. At the bottom left, there is a note '* Required Fields'. At the bottom right, there are two buttons: 'Request Login' and 'Forgot Password?'.


- Click **Log In** to log into ECONirman WBP Tool.
- The **Projects** page opens. See § 5 to learn how to [manage projects](#).

4.3.3. Retrieve Forgotten Password

A forgotten password can be retrieved from any of the following two locations:

- **Request Login** dialog box (see § 4.3.1 [New User](#))
- **Log In** dialog box (see § 4.3.2 [Log In](#))

On the dialog box, click **Forgot Password?** to retrieve the password of an existing user. The **Forgot Password** dialog box appears.



The screenshot shows a 'Forgot Password?' dialog box with a light blue background. At the top left, the title 'Forgot Password?' is displayed. Below it, there is one input field: '* User Name/Email' containing 'irgeco3@gmail.com'. A blue 'Submit' button is positioned below the input field. At the bottom left, there is a note '* Required Fields'. At the bottom right, there are two buttons: 'Request Login' and 'Return to Login'.

- Enter the registered e-mail address.
- Click **Submit** to send the request for password retrieval to the registered e-mail address.
- Open the e-mail (external of ECONirman WBP Tool) and click the hyperlink available therein.
- The **Reset Password** dialog box appears in ECONirman WBP Tool with the reset key auto-populated.

Reset Password

* Email

* Reset Key

* New Password


* Confirm Password

* Required Fields

- Enter the new password and confirm it.
- Click **Submit** to reset the password.

4.3.4. Change Password and Update Profile

Click on logged in user's e-mail address at the top right corner of the page to change the password or update the user details. The **Update Profile** dialog box appears.



The screenshot shows a dialog box titled "Update Profile" with a close button (X) in the top right corner. The dialog contains the following fields and values:


- New Password: [Empty text box]
- Confirm Password: [Empty text box]
- * Full Name: Firstname Lastname
- Company Name: IRG ECO-III
- Job Title: Senior Architect (highlighted with a blue selection box)
- Industry: Energy

At the bottom of the dialog, there are three buttons: "Logout", "OK", and "Cancel".

- To change the password, enter the new password, confirm it, and click **OK**.
- To update the profile, enter the relevant details and click **OK**.

4.3.5. Log Out

After using ECONirman WBP Tool, click **Logout** at the top right corner of the page to log out.


 It is imperative to save the entered details before logging out. Any unsaved details will be otherwise lost.

5. Manage Projects

After logging into ECONirman WBP Tool for the **first time**, a blank project list is displayed. However, if the project records were **already created** by an existing user by logging in earlier, then those are listed.

Organization Name	Project Name	Last Modified	Creation Date	Type	Has Results	Square Meters	City
IRG ECO-III	Centre 2	9/7/2011	9/7/2011	Office	No	7500	Mumbai
IRG ECO-III	Centre 1	9/7/2011	9/7/2011	Office	No	7500	Mumbai

A	Actions: <ul style="list-style-type: none">• Create new project (see § 5.1.1)• Existing project:<ul style="list-style-type: none">◦ Edit (see § 5.1.2)◦ Delete (see § 5.1.3)◦ Copy (see § 5.1.4)
B	Filter the list of projects (see § 5.2)
C	The list of projects

 The project list can be sorted by clicking the column heading. For example, click the column heading **Has Results** to view the projects sorted as per the availability of the simulation result. **Yes** indicates that simulation results are available for the project and **No** indicates that they are not.

5.1. Project Actions

The building projects can be created, edited, deleted, and copied. These actions are explained in the following sub-sections.

5.1.1. Create Project


To create a new project for assessing conformance, click **New** at the top right corner of the page. The [Project Information](#) tab opens (see § 6).

5.1.2. Edit Project


To edit an existing project, click on a project in the list and then click **Edit** at the top right corner of the page. The [Project Information](#) tab opens with the underlying project details (see § 6).

5.1.3. Delete Project

To delete an existing project, click on a project in the list and then click **Delete** at the top right corner of the page. A confirmation dialog box appears.



Click **Yes** to delete the project. The project gets deleted.

 There is no way to undo this action and retrieve a deleted project.

5.1.4. Copy Project

To make a copy of an existing project, click on a project in the list and then click **Copy** at the top right corner of the page.

- The [General](#) sub-tab (§ 6.1) under the **Project Information** tab opens.
- The project name in the **Project Name** field is suffixed with the word '**Copy**'. Change this, if required.
- Click **Save** at the top right corner of the page.

The screenshot displays the 'ECO nirman' web application interface. At the top, it shows the user is logged in as 'irgeco3@gmail.com'. The main header includes the 'ECO nirman' logo and navigation links for 'About' and 'Help'. Below the header, the project name 'Centre 2 - Copy' is displayed, along with 'Save' and 'Return to Project List' buttons. The 'Project Information' tab is active, showing a form with the following fields:

Project Information	
Project Name:	Centre 2 - Copy
Organization:	IRG ECO-III
Created Date:	8/24/2011 2:09:25 PM
Last Modified:	8/24/2011 2:09:25 PM

The 'Location' section includes:

Location	
Project Address:	Centre 2 Mumbai Maharashtra
State/UT:	Maharashtra
City:	Mumbai

The 'Building Use' and 'Dimensions' sections include:


Building Use		Dimensions	
Building Type:	Office	Total Interior Floor Area:	7500 (m ²)
Building Occupancy:	Daytime Use	Number of Floors:	5
		Floor to Floor Height:	4 (m)

At the bottom of the form, there are 'Apply' and 'Revert' buttons.

A copy of the project is created with all the information from the original project retained as is.

5.2. Filter Project List


The projects in the list can be filtered to view only the relevant ones. This feature is particularly useful as the number of projects increase and the list gets bigger.




Filter by: Last Modified Date Creation Date No Filter Start: 3/11/2011 End: 7/9/2011 Apply Filter




The following two date filters are available:

Last Modified Date	The date on which an existing project was last modified
Creation Date	The date on which a new project was created

- Select the radio button corresponding to the desired date filter.
- Define the date range:
 - To set the start date, click  corresponding to **Start**. Select the date from the calendar that appears.



- To set the end date, click  corresponding to **End**. Select the date from the calendar that appears.

 Click  or  to navigate to the previous or the next calendar month respectively.

- Finally, click **Apply Filter** to set the filter. Only the projects within the defined date range get listed.

 Select **No Filter** radio button to remove the set filter.

6. Project Information

The **Project Information** tab opens upon clicking [New](#), [Edit](#), or [Copy](#) on the [Projects](#) page. The tab comprises of two sub-tabs on the left side that are explained in the following sub-sections.



Certain input fields get customized across the tool according to the details entered under these sub-tabs.

6.1. General

This sub-tab is used to capture the name, location, and basic information of the building.



It is important to enter correct information under this sub-tab before proceeding any further. Making changes on this sub-tab after providing inputs elsewhere in the tool will reset the defaults for the project. All the inputs across the tool will be lost for that project.

The screenshot displays the 'ECO nirman' software interface. At the top left is the logo 'ECO nirman' with the tagline 'Whole Building Performance'. On the top right are 'About' and 'Help' links. Below the logo, the current project is identified as 'Project: Centre 2'. There are 'Save' and 'Return to Project List' buttons. The main interface is divided into several tabs: 'Project Information', 'Building Use', 'Envelope', 'HVAC', and 'Conformance Check'. The 'Project Information' tab is active. On the left side, there are sub-tabs for 'General' and 'Building', with 'Building' selected. The 'Project Information' section contains the following fields:

Project Information	
Project Name:	Centre 2
Created Date:	9/7/2011 7:48:39 AM
Organization:	IRG ECO-III
Last Modified:	9/7/2011 7:50:33 AM

The 'Location' section contains:


Location	
Project Address:	Centre 2 Mumbai Maharashtra
State/UT:	Maharashtra
City:	Mumbai

The 'Building Use' and 'Dimensions' sections contain:

Building Use	Dimensions
Building Type:	Office
Building Occupancy:	Daytime Use
Total Interior Floor Area:	7500 (m ²)
Number of Floors:	5
Floor to Floor Height:	4 (m)

At the bottom of the form are 'Apply' and 'Revert' buttons.

- Enter/edit the details such as project and organization names, location details, building type and occupancy, and dimensions.

 Enter the exact **Total Interior Floor Area** of the building. Certain input fields get defaulted across the tool based on this information.

- Click **Apply** at the bottom of the page.




At this point:


- The creation and modification dates along with the timestamps are displayed.
- Other tool tabs and sub-tabs get activated.

Revert (at the bottom of the page) is used to discard the entered details and revert to the previously **saved** ones.

Click **Return to Project List** at the top right corner of the page at any point to access the list of projects. A dialog box appears to save the project.



Click **Yes** to save.

 It is imperative to save the project before accessing the list of project. Any unsaved project details under the tabs/sub-tabs will be otherwise lost.

6.2. Building

This sub-tab is used to define the shape, dimensions, and orientation of the building.



The building geometry inputs can be specified by selecting a building floor plan shape and modifying the proportions and orientation to represent the building to be assessed for conformance.








To keep the inputs easy, five typical building plan shapes are provided in the tool (see [§ 6.2.1](#)). A shape can be customized by modifying the building dimensions (see [§ 6.2.2](#)). Also, the orientations can be defined at 45° increments by rotating the shape (see [§ 6.2.3](#)).

6.2.1. Building Shape


Select the shape of the building from the available five options.


Building Shape

- 
- 
- 
- 
- 

6.2.2. Building Dimensions


The dimensions are displayed on the basis of the selected building shape. Change the values to customize the dimensions.


 If the calculated area while customizing the dimensions does not reconcile with that defined under the [General](#) sub-tab (§ 6.1), a warning icon is displayed.



Label	Value (m)
A	44.8
B	32.4
C	22.4
D	22.4
E	22.4
F	10

To resolve:

- Hover the mouse pointer over the  icon to read the warning message. It displays **Total Building Area Specified** and **Building Area Calculated from Dimensions**.



The building dimensions entered below result in a calculated total building area that is significantly different than the specified total building area specified (under the General tab).

Please check your entries.


Total Building Area Specified: 7500
Building Area Calculated from Dimensions: 6137.6

- Assess the variance.


- Make appropriate corrections so that the area calculated from the dimensions matches with that defined under the [General](#) sub-tab (§ 6.1).



The building shape in the center of the page changes dynamically in proportion to the customized dimensions.




The following are certain examples of building shapes derived by modifying the dimensions:



6.2.3. Building Orientation

The orientation of the building can be defined by rotating the building clock-wise at 45° intervals. To rotate, click the white arrow and simultaneously drag the mouse pointer clock-wise.




The building can be oriented in the following eight cardinal/ordinal directions:

- North
- North-East
- East
- South-East
- South
- South-West
- West
- North-West

7. Building Use


In EConirman WBP Tool, click the **Building Use** tab to define space use and zoning. The tab comprises of two sub-tabs on the left side that are explained in the following sub-sections.

 Certain input fields get customized across the tool according to the details entered under these sub-tabs.

7.1. Space Use

This sub-tab is used to define the area allocated to each space type and the corresponding loads, lighting details, thermal comfort, and operating schedules.

A key task in modelling the *Proposed Design* is assigning space use classifications to different areas of the building. These classifications are used to assign lighting power density assumptions and to differentiate areas within the building that may have different operating schedules and characteristics (for example, thermostat settings and ventilation rates).



The screenshot displays the 'Building Space Use' sub-tab in the EConirman WBP Tool. The interface shows a project named 'Centre 2' and a table of space types with their respective metrics. The table includes columns for Space Type, Allocated Area (m²), Allocated (%), Light (W), Plug Loads (W / m²), Density (m²), People Heat (W), and Ventilation. The table is scrollable and includes an 'Edit' button for each row.

	Space Type	Allocated Area (m ²)	Allocated (%)	Light (W)	Plug Loads (W / m ²)	Density (m ²)	People Heat (W)	Ventilation
Edit	Open Office	2625	35	11.8	12.9	60	131.9	DefinedFI
Edit	Enclosed Office	1875	25	11.8	12.9	9.3	131.9	DefinedFI
Edit	Circulation	1350	18	5.4	1.1	18.6	131.9	DefinedFI
Edit	Mechanical Electrical Room	450	6	16.1	2.2	25.5	131.9	NA
Edit	Storage	375	5	8.6	1.1	25.5	131.9	NA
Edit	Medium Conference Room	300	4	14	10.8	15	117.2	DefinedFI
Edit	Data Center	150	2	11.8	129.2	18.6	117.2	DefinedFI
Edit	Lobby	150	2	14	2.7	9.3	131.9	DefinedFI
Edit	Restrooms	150	2	9.7	2.2	25	131.9	NA
Edit	Large Conference Room	75	1	14	10.8	15	117.2	DefinedFI


Some space types are defaulted to be unconditioned, which can be modified. Unconditioned zones are modelled identically in the *Standard Design* and the *Proposed Design* models. The following is the modelling method:


- All unconditioned thermal zones have their cooling set points as 50°C and heating set points as 8°C.
- All unconditioned thermal zones are assigned to one air handling unit (AHU).

Thus, the cooling and the heating for the AHU with unconditioned zones are not activated by the simulation engine in the simulation run.

7.1.1. Area Allocation


Against each space type, enter the area to be allocated to it under the **Allocated Area (m²)** column.

 The total area allocated to all space types must be equal to the **Total Interior Floor Area** defined under the [General](#) sub-tab (§ 6.1). If it is higher or lower, the variance is displayed.

Allocated/Total Square Meters: 7550/7500  +50
--

7.1.2. Lighting

Click **Edit** corresponding to a space type to edit its lighting details. The **Edit Space Type** dialog box appears with the default lighting details.

 It is important to replace the defaults with the inputs that match the actual building design in order to get the correct simulation results for conformance.

The screenshot shows a software dialog box titled "Edit Space Type: Open Office". It has four tabs: "Lighting", "Loads", "Thermal Comfort", and "Schedules". The "Lighting" tab is active. Under the "Lighting" section, there is a "Light Power Density" input field with the value "11.8" and the unit "(W / m²)". Under the "Lighting Controls" section, there are three options: "Occupancy sensor control" (checked), "Daylighting control in daylighted zones for this space type" (unchecked), and "Automatic dimming control" (selected with a radio button). At the bottom right, there are "OK" and "Cancel" buttons.

- Define lighting power density (LPD).
- Enter the details of lighting controls.
- Click **OK** to set the lighting details.

7.1.3. Loads

Click **Edit** corresponding to a space type to edit its loads. The **Edit Space Type** dialog box appears. Click the **Loads** tab.



Enter these loads to get a more accurate prediction of the overall energy use of the building. In case of a doubt, leave the defaults in place. These loads are identical in both the *Proposed Design* and the *Standard Design* models, and therefore do not influence the energy efficiency of the design.

The screenshot shows a software dialog box titled "Edit Space Type: Open Office" with a close button (X) in the top right corner. The dialog has four tabs: "Lighting", "Loads", "Thermal Comfort", and "Schedules". The "Loads" tab is active. Below the tabs is a section titled "Loads" with a light blue header. This section contains the following fields and options:

- Plug Loads:** A text input field containing "12.9" followed by the unit "(W / m²)".
- Process Loads:** A text input field containing "0" followed by the unit "(W / m²)".
- Sensible heat load to space:** A text input field containing ".00" followed by a percent sign "%".
- Latent heat load to space:** A text input field containing ".00" followed by a percent sign "%".
- Process Load Source:** A group of four radio button options:
 - Natural Gas
 - Chilled Water
 - Hot Water
 - Other (non-utility) fuel

At the bottom right of the dialog box, there are two buttons: "OK" and "Cancel".

- Define the plug and process loads.
 - Enter the **Plug Loads** (power density for the equipment that is plugged into the electrical outlets).
 - For equipment that uses forms of energy other than electricity and release heat into the space type, enter the **Process Loads**.

Sensible heat load to space is the cooling load caused by heat added to the space that causes the air temperature in that space to rise. **Latent heat load to space** is the cooling load caused by adding moisture to the air in that space.



Both these loads are percentages of the total process load, and the sum of both cannot exceed 100 percent. The sum may be less than 100 percent (for example, part of the load may be directly exhausted from a kitchen).

- Finally, click **OK** to set the loads.

7.1.4. Thermal Comfort

According to Appendix A of the ECBC, the floor area of a building is categorized as following:

- **Conditioned space:** This is a cooled space, heated space, or directly conditioned space in the building.
- **Semi-heated/cooled space:** This is an enclosed space within a building that is heated by a heating system whose output capacity is greater than or equal to 10.7 W/m² of floor area but is not a conditioned space.
- **Unconditioned space:** This is neither conditioned space nor semi-heated space. Crawl spaces, attics, and parking garages with natural or mechanical ventilation are not considered as enclosed spaces.

Click **Edit** corresponding to a space type to edit its thermal comfort details. The **Edit Space Type** dialog box appears. Click the **Thermal Comfort** tab.

The screenshot shows the 'Edit Space Type: Open Office' dialog box with the 'Thermal Comfort' tab selected. The dialog is divided into several sections:

- People:** Max Density (60 m² / person), Sensible Heat Gain (73.3 W / person), Latent Heat Gain (58.6 W / person).
- Space Conditioned:** A checked checkbox.
- Thermostat Settings:** Heating and Cooling settings for Occupied and Unoccupied states.

	Heating	Cooling	(°C)
Occupied	18	24.4	
Unoccupied	8	50	
- Humidity Control:** Maximum and Minimum humidity control settings, both set to 0%.
- Ventilation Requirements:** Radio buttons for 'People Requirement' (selected) and 'Minimum Air Changes'.

Requirement	Value	Unit
People Requirement	0	(m ² / s / person)
Addl Space Vent. Requirement (ASHRAE 62 requirement)	0	(m ² / s / m ²)
Minimum Air Changes - Unoccupied (0%)	0.2	(/ hr)
Minimum Air Changes - Occupied (>0%)	1	(/ hr)


Buttons for 'OK' and 'Cancel' are located at the bottom right.

- Define people related details.



Leave the defaults in place if this information is not available.

- Define conditioned space details (optional) such as thermostat settings, humidity control, and ventilation requirements.

 It is important to replace these defaults with the inputs that match the actual building design in order to get the correct simulation results for conformance.

- Click **OK** to set the thermal comfort.


7.1.5. Schedules

Schedules are used to define an hour-by-hour value that represents the percentage of the maximum internal load. It applies to lighting power density, miscellaneous equipment (plug load or process load) power density, and building occupancy.

Schedules can have a large impact on energy consumption. The user needs to specify weekday (Monday-Friday) and weekend (Saturday and Sunday) operations in each schedule.

ECONirman WBP Tool simulates the *Proposed Design* and the *Standard Design* with identical schedules.

Click **Edit** corresponding to a space type to edit its operating schedules. The **Edit Space Type** dialog box appears. Click the **Schedules** tab.



Season

Select a season from the drop-down menu.




Season: Regular (Default) [v] [New] [Edit] [Delete]



Regular (Default) is the default season, which cannot be deleted.

To create a new season, click **New**. The **Add New Season** dialog box appears.



Add New Season [x]

Name: Winter


Start Date: November 1

End Date: February 28

[OK] [Cancel]

- Enter the name of the season.
- Define the period (start and end months/days).
- Click **OK**.

To edit a season, select it from the drop-down menu and click **Edit**. The **Edit Season** dialog box appears.



Edit Season [x]

Name: Winter Nov-Feb


Start Date: November 1

End Date: February 28

[OK] [Cancel]

Make the changes and click **OK**.

To delete a season, select it from the drop-down menu and click **Delete**. A confirmation dialog box appears.



Click **OK** to delete the season. The season gets delisted from the drop-down menu.

Days

Toggle between **Weekday** (Monday-Friday) and **Weekend** (Saturday and Sunday) tabs to view the corresponding schedules.




Schedule

The schedule is plotted for the following four categories:

- Occupancy
- Lighting
- Plug Load
- Process Load


Select a category to view its pattern during the 24 hours of the day.



The selected category is represented by a solid line, whereas the other three are represented by dotted lines.



- Select hour-based data point(s) and drag the mouse pointer to change the pattern.
- Click **Select All** to select all the data points (all 24 hours).
- Click **Unselect All** to unselect the selected data point(s).
- Select hour-based data point(s) and right-click on the mouse. A context menu appears.



- Select a category under **Match the schedule** to match the selected hour-based data point(s) to that category's hour-based data point(s).
- Select **0%** to set the selected hour-based data point(s) to 0%; select **100%** to set the selected hour-based data point(s) to 100%; select **Custom Percentage** to define a customized percentage for the selected hour-based data point(s).

7.2. Zoning

This sub-tab is used to provide the information to generate the thermal zones of the building.

ECONirman WBP Tool uses the building geometry (shapes, dimensions, and orientations), the specified space types, and zoning affinities to create the zones for both the *Proposed Design* and the *Standard Design* models.


In ECONirman WBP Tool, click the **Zoning** sub-tab to define the zones.

Project: test2 Save Return to Project List

Building Zoning Apply Defaults

For spaces on the top or ground floor, select the Floor Affinity. For spaces on the perimeter, enter the length occupied by a space type along the perimeter wall, by building orientation. See [Help](#) for additional explanation and examples.

Space Type	Floor Affinity	N (m)	E (m)	S (m)	W (m)	Perimeter Request (m)
Open Office	Top	126.2	126.2	123	126.2	501.7
Enclosed Office	Ground	90.2	90.2	87.9	90.2	358.3
Circulation	Any	0	0	0	0	0.0
Mechanical Electrical Room	Any	0	0	0	0	0.0
Storage	Any	0	0	0	0	0.0
Medium Conference Room	Any	0	0	5.7	0	5.7
Data Center	Any	0	0	0	0	0.0
Lobby	Any	7.2	7.2	7	7.2	28.7
Restrooms	Any	0	0	0	0	0.0
Perimeter Request (m):		223.6	223.6	223.6	223.6	
Perimeter Available (m):		223.6	223.6	223.6	223.6	

 The pre-populated perimeter lengths are provided for convenience only. It is important to provide the inputs that represent the actual building to create the zones correctly.

7.2.1. Floor Affinity

Select **Floor Affinity (Any, Ground, Top)** for a space type from the drop-down menu adjacent to it.

- **Any:** This sets the zone(s) of the space type be placed on any floor within the building
- **Ground:** This sets a priority for the zone(s) of the space type to be placed on the ground floor of the building.
- **Top:** This sets a priority for the zone(s) of the space type to be placed on the upper level, or the top floor of the building.

7.2.2. Perimeter Allocation




Click **Apply Defaults** to set the default values for the space types for the selected building shape vis-à-vis the area allocated under the [Building](#) sub-tab (§ 6.2). However, if this is clicked after any changes are made under the **Zoning** sub-tab, then those **changes will be lost** and the defaults will be re-applied.

Perimeter orientation affinities: Perimeter zones in the model need to reflect the perimeter space types that are along the exterior walls in the building. To achieve this:

- Mark up the plans to classify the rooms by space types (see example below).
- Mark up the perimeter lengths of the spaces.
- Add the total length of a space type along each orientation and enter the sum in the zoning table in the tool.

Example:

The following are the illustrations of a 3-storied building with its plans marked up as space types along with the dimensions of the length occupied by each space type on the perimeter.



The following table depicts how floor affinities and perimeter affinities are calculated from the plans above.

Floor Affinity: Since Lobby and Storage are only on the ground floor, they get **Ground** as the floor affinity. Medium Conference is only on the top floor, so it gets **Top** as the floor affinity.

Perimeter Affinity: For each orientation, add up the linear exposed length for a space type and enter it in the corresponding cell in the tool. On the South face, the circulation has 30 m on the first floor and 30 m exposed on the second floor. Therefore, the perimeter affinity for Circulation on the South is 30 m + 30 m = 60 m.

Space Type	Floor Affinity	North (m)	East (m)	South (m)	West (m)
Open Office	Any		60	20 + 30 + 20 + 20 + 30 + 20	30 + 30 + 40 + 30 + 40 + 30
Private Offices	Any	60 + 30	80 + 50	10	10 + 10
Circulation	Any			30 + 30	
Medium Conference	Top	30	30		
Rest Rooms	Any			10 + 10 + 10	
Storage	Ground	60	20		20
Lobby	Ground			30	

8. Envelope

The building envelope refers to the exterior façade and roof, and is comprised of opaque components and fenestration systems. Opaque components include walls and roofs; fenestration systems include windows and skylights.

The envelope protects the building's interior and occupants from the weather conditions and shields them from other external factors such as noise and air pollution. Envelope design strongly affects the visual and thermal comfort of the occupants, as well as the energy consumption of the building.



Refer to **Building Envelope** tip sheet available at http://eco3.org/?file_id=19 to learn more about envelope.

In EConirman WBP Tool, click the **Envelope** tab to define the windows, walls, roofs, and skylights of a building. The tab comprises of two sub-tabs on the left side that are explained in the following sub-sections.

8.1. Windows and Walls

This sub-tab is used to define the construction and Window Wall Ratio (WRR), and vertical and horizontal shading.

The screenshot shows the EConirman WBP Tool interface. The main navigation bar includes 'Project Information', 'Building Use', 'Envelope', 'HVAC', and 'Conformance Check'. The 'Envelope' tab is selected. On the left, there are sub-tabs for 'Windows and Walls' and 'Roofs and Skylights'. The 'Windows and Walls' sub-tab is active, displaying a table with columns for North (N), East (E), South (S), and West (W). Each column has an 'Edit' button above it. The table contains the following data:

	N	E	S	W
Wall Construction	100mm RCC, 75mm EPS interior insulation	100mm RCC, 75mm EPS interior insulation	100mm RCC, 75mm EPS interior insulation	100mm RCC, 75mm EPS interior insulation
Window Construction	Double pane, 2 Low-E clear, UPVC frame, sliding	Double pane, 2 Low-E clear, UPVC frame, sliding	Double pane, 2 Low-E clear, UPVC frame, sliding	Double pane, 2 Low-E clear, UPVC frame, sliding
Window/Wall Ratio	0.4	0.4	0.4	0.4
Vertical Shading	None	None	None	None
Horizontal Shading	None	None	None	None

Click **Edit** above a direction (north, east, south, or west) to edit the details of windows and walls for that direction. The **Windows and Walls** dialog box appears with pre-populated default values.

Windows and Walls

Wall Construction: 100mm RCC, 75mm EPS interior insulation, U-factor: 2.5
NOTE: All assemblies listed here include 18mm external and 12mm internal cement plaster and/or 18mm external and 12mm internal screed plaster (with insulation) wherever applicable. Add Custom

Window Construction: Double pane, 2 Low-E clear, UPVC frame, sliding, U-factor: 3.12, SHGC: 0.42, VT: 0.44
NOTE: These fenestration properties are calculated using WINDOW, THERM and Optics software tools as part of a study done by CSEE, CEPT University. Add Custom

Window/Wall Ratio: 0.4

Horizontal Shading

Extension From Building: 0 (m)
 Distance Above Window: 0 (m)
 Height of Window: 0 (m)
 Transparency: 0.0

Vertical Shading

Extension From Building: 0 (m)
 Interval Between Fins: 0 (m)
 Transparency: 0.0

Apply Selection To: All N E S W

OK Cancel




The changes made for a direction (for example, north) can be replicated for other direction(s) (east, south, west) by selecting the relevant check boxes at the bottom of the **Windows and Walls** dialog box.

Apply Selection To: All N E S W

The following sub-sections explain how to edit the details of windows and walls.

8.1.1. Wall Construction


To change **Wall Construction**, click  to view the drop-down list of wall assemblies.



- Select the desired assembly.
- If required, make other changes on the **Windows and Walls** dialog box.
- Finally, click **OK**.

Customized Wall Assembly

To add a customized assembly, click **Add Custom**. The **Custom Wall Material** dialog box appears.



- Enter the name of the customized assembly.
- Enter the corresponding U-factor.



This is an assembly U-factor that includes the effect of air-film on both sides of the wall; this value is not always calculated as the sum of the thermal resistance properties of the wall layers. If required, consult the insulation or

building material manufacturer and ask for a calculation of the assembly U-factor.


- Click **OK**.

The customized assembly gets listed in the drop-down list with the word ‘**Custom**’ prefixed to it.

- If required, make other changes on the **Windows and Walls** dialog box.
- Finally, click **OK**.

8.1.2. Window Construction


To change **Window Construction**, click  to view the drop-down list of window assemblies.



- Select the desired assembly.
- If required, make other changes on the **Windows and Walls** dialog box.
- Finally, click **OK**.

Customized Window Assembly

To add a customized assembly, click **Add Custom**. The **Custom Window** dialog box appears.

- Enter the name of the customized assembly.
- Enter the corresponding glazing assembly U-factor.
 -  This is not the centre of glass U-factor that is listed in the glass manufacturer's catalogue. To get the U-factor of the overall fenestration product, contact the glass manufacturer and ask for it based on the average size of the window units.
- Enter solar heat gain coefficient.
- Enter visible light transmittance.
- Click **OK**.

The customized assembly gets listed in the drop-down list with the word '**Custom**' prefixed to it.

- If required, make other changes on the **Windows and Walls** dialog box.
- Finally, click **OK**.

8.1.3. Window Wall Ratio

This is the ratio of the vertical fenestration (window) area to gross exterior wall area. The gross exterior wall area is measured horizontally from the exterior surface; it is measured vertically from the top of the floor to the bottom of the roof.

 The HVAC engineer for the building is likely to have this information.


On the **Windows and Walls** dialog box:

- Enter Window Wall Ratio.
- Make other changes, if required.

- Finally, click **OK**.


8.1.4. Shading

The overhangs on a building can reduce solar gains. The inputs for both horizontal shading devices and vertical fins that extend out of a building can be provided in the tool.




Horizontal Shading

<input checked="" type="checkbox"/> Horizontal Shading		
Extension From Building:	<input type="text" value="0.7"/>	(m)
Distance Above Window:	<input type="text" value="0.2"/>	(m)
Height of Window:	<input type="text" value="1"/>	(m)
Transparency:	<input type="text" value="0.5"/>	

- Select **Horizontal Shading** check box to enter its details.
 -  See the illustration above to understand the input fields.
- Enter the following details:
 - The extension (in meters) of the overhang from the building.
 - The distance (in meters) of the overhang from the window.
 - The height (in meters) of the windows.
 - The transparency of the horizontal shading.
- If required, make other changes on the **Windows and Walls** dialog box.
- Finally, click **OK**.


Vertical Shading

<input checked="" type="checkbox"/> Vertical Shading	
Extension From Building:	<input type="text" value="0.7"/> (m)
Interval Between Fins:	<input type="text" value="0.1"/> (m)
Transparency:	<input type="text" value="0.5"/>

- Select **Vertical Shading** check box to enter its details.
 -  See the illustration above to understand the input fields.
- Enter the following details:
 - The extension (in meters) of the overhang from the building.
 - The interval (in meters) between the fins.
 - The transparency of the vertical shading.
- If required, make other changes on the **Windows and Walls** dialog box.
- Finally, click **OK**.

8.2. Roofs and Skylights

This sub-tab is used to define the construction of building roofs, the skylight roof ratio (SRR), and the roof reflectivity.





The screenshot displays the 'ECO nirman' software interface. At the top left is the logo 'ECO nirman' with the tagline 'Whole Building Performance'. To the right are 'About' and 'Help' links. Below the logo is a blue bar with 'Project: Centre 2' and 'Save' and 'Return to Project List' buttons. A navigation menu includes 'Project Information', 'Building Use', 'Envelope', 'HVAC', and 'Conformance Check'. On the left, a sidebar has 'Windows and Walls' and 'Roofs and Skylights' (the active section). The main content area is titled 'Roofs and Skylights' and contains:

- 'Roof Construction:' with a dropdown menu showing '150mm RCC slab, 65mm EPS underdeck insulation, U-factor: 2.32' and a small downward arrow.
- A note: 'NOTE: All assemblies listed here include 75mm external cement sand render and 12mm internal cement plaster or screed plaster (with insulation) wherever applicable.' followed by an 'Add Custom' button.
- 'Skylight/Roof Ratio:' with an input field containing '0.25'.
- 'Roof Reflectivity:' with an input field containing '0.8'.

The following sub-sections explain how to edit the details of roofs and skylights.

8.2.1. Roof Construction

To change **Roof Construction**, click  to view the drop-down list of roof assemblies and select the desired one.



Customized Roof Assembly

To add a customized assembly, click **Add Custom**. The **Custom Roof Material** dialog box appears.

Custom Roof Material [X]

Name: 150mm RCC slab, 150mm XPS overdeck insulation, U-factor: 1.05

U-factor: 1.06 (W/m²·K)

OK Cancel

- Enter the name of the customized assembly.
- Enter the corresponding U-factor.



This is an assembly U-factor that includes the effect of air-film on both sides of the wall; this value is not always calculated as the sum of the thermal resistance properties of the wall layers. If required, consult the insulation or building material manufacturer and ask for a calculation of the assembly U-factor.

- Click **OK**.

The customized assembly gets listed in the drop-down list with the word '**Custom**' prefixed to it.

8.2.2. Skylight Roof Ratio

This is the ratio of the total skylight area of the roof, measured to the outside of the frame, to the gross exterior roof.

Enter **Skylight/Roof Ratio**.

8.2.3. Roof Reflectivity

As per the ECBC, for the *Standard Design*, exterior roof surfaces, other than those with ventilated attics, must be modelled assuming a surface reflectance value of 0.30. However, if a *Proposed Design* calls for a reflective roof surface, the model may assume a long-term average reflectance of 0.45. This results in lower heat absorption of the reflective surface and makes a conservative allowance for the degradation of reflectivity over its lifetime. For this exception to be allowed, the specified reflectance of the roof in the *Proposed Design* must exceed 0.70 and its emittance must exceed 0.75.

Enter **Roof Reflectivity**.

9. Heating, Ventilation and Air Conditioning

Heating, Ventilation and Air Conditioning (HVAC) refers to the equipment, distribution systems, and terminal units that fulfil, either collectively or individually, the heating, ventilation, or air-conditioning requirement of a building or a portion of it. HVAC systems account for a significant portion of a commercial building's energy use.

HVAC energy use can increase or decrease significantly depending on how efficiently the air side systems and central plant operate. Proven technologies and design concepts can be used to build efficiencies in the systems and generate significant energy and cost savings. An optimal HVAC design considers all the interrelated building systems while addressing indoor air quality, thermal comfort, energy consumption, and environmental benefits.


HVAC systems broadly comprise of **Air Systems**, **Cooling Plant**, and **Heating Plant**.

The following is the list of HVAC systems:

Name	Characteristics
Central Plant VAV	Central Variable Air Volume (VAV) AHU with cold and hot water loops from a central chiller and a boiler plant
Central Plant Constant Volume	Central constant volume reheat AHU with cold and hot water loops from a central chiller and boiler plant
Packaged VAV	Packaged VAV system with direct-extension (DX) coil
Packaged Rooftop CAV [†]	Packaged constant volume system with DX coil
Split system	Split systems, high wall or cassette type
Through-wall system	Mounted through the wall, typically in hotels
Window unit	Unitary window mounted units

[†] This is a single zone system, where each thermal zone will be assigned a separate system.



Refer to **HVAC System** tip sheet available at http://eco3.org/?file_id=25  to learn more about HVAC.

In EConirman WBP Tool, click the **HVAC** tab to define HVAC systems and assign them to different space types or zones. The tab comprises of two sub-tabs on the left side that are explained in the following sub-sections.



Certain input fields get customized across the tool according to the details entered under these sub-tabs.

9.1. Systems

This sub-tab is used to add new HVAC systems and edit them. The default system that appears will be modelled in the *Standard Design*. If this is the system in the *Proposed Design*, then edit its inputs. To change the systems to match the *Proposed Design*, add other systems ([§ 9.1.1](#)) to match those in the building and delete the default system shown by the tool ([§ 9.1.3](#)).

The screenshot shows the ECO nirman software interface. At the top left is the logo 'ECO nirman Whole Building Performance'. The top right has 'About' and 'Help' links. Below the logo is a blue bar with 'Project: Centre 1' and 'Save' and 'Return to Project List' buttons. A navigation menu below the bar has tabs for 'Project Information', 'Building Use', 'Envelope', 'HVAC', and 'Conformance Check'. The 'HVAC' tab is selected. On the left is a sidebar with 'Systems' and 'Assignments' buttons. The main content area is divided into three sections: 'Air Systems', 'Cooling Plant', and 'Settings'. The 'Air Systems' section has an 'Add' and 'Delete' button and a table with one row: 'Central Plant CAV' of type 'CentralCAV'. The 'Cooling Plant' section has a table with one row: 'Chiller Plant' of type 'Chilled Water Plant'. The 'Settings' section has a checked checkbox for 'Hot Water Service'.

Name	Type
Central Plant CAV	CentralCAV

Name	Type
Chiller Plant	Chilled Water Plant


Hot Water Service



Select **Hot Water Service** under **Settings** at the bottom of the page if the building has water heating facility.

9.1.1. Add System

Click **Add** to add a new system. The **Add HVAC Air System** dialog box appears.



- Select the system from **Air System Type** drop-down menu.
- Click **OK**.

The system gets listed under **Air Systems**.

Air Systems			Add	Edit	Delete
	Name	Type			
Edit	Central CAV	CentralCAV			
Edit	Single Zone	SingleZone			




Cooling Plant and/or **Heating Plant** are added by the tool automatically if a system with a plant is added.

9.1.2. Edit System

To edit a system, click **Edit** adjacent to its name. The diagram of the system and its properties appear.

Air Systems



Specify the following properties (customizable inputs) of the air system:

Properties (Custom Inputs)	Air System Type						
	Central Plant VAV	Central Plant Constant Volume	Packaged VAV	Packaged Rooftop CAV	Split System	Through -wall System	Window Unit
Air System Inputs							
System Name	✓	✓	✓	✓	✓	✓	✓
Air Flow Sizing	✓	✓	✓	✓	✓	✓	✓
Maximum Supply Air Flow (l/s)	✓	✓	✓	✓	✓	✓	✓
Use	✓	✓	✓	✓	✓	✓	✓

Properties (Custom Inputs)	Air System Type						
	Central Plant VAV	Central Plant Constant Volume	Packaged VAV	Packaged Rooftop CAV	Split System	Through -wall System	Window Unit
Seasonal Schedule							
Cooling Coil							
Cooling Source	✓	✓	✓	✓	✓	✓	✓
Heating Coil							
Heating Source	✓	✓	✓	✓	✓	✓	✓
Supply Fan							
Location	✓	✓	✓	✓	✓	x	x
Static Pressure (Pa)	✓	✓	✓	✓	✓	x	x
Return Fan							
Static Pressure (Pa)	✓	✓	✓	✓	✓	x	x
Outside Air Control							
Economiz- ing	✓	✓	✓	✓	✓	x	x
Exhaust Air Heat Recovery							
Type	✓	✓	✓	✓	✓	x	x
Terminal Units							
Includes Reheat Coil	✓	✓	✓	✓	✓	x	x
Source	✓	✓	✓	✓	✓	x	x

After specifying the properties, click **OK** to define the air system.

Cooling and Heating Availability Schedules: The tool gives an option to select seasonal availability of heating and cooling for each individual HVAC system included in the building. If the seasonal availability is not selected by the user, the tool allows heating and cooling to be available through the entire year. Select the seasonal option if heating is to be turned off in the non-winter months in a cold

climate, or if cooling is to be turned off in temperate or cool months. This will ensure EPI predictions that are not unrealistically high. This schedule is identical for the *Standard Design* and the *Proposed Building* models. The tool arrives at the season schedule using the following algorithm:

- If the monthly average **dry-bulb temperature** is more than 26°C AND monthly average **enthalpy** is more than 60 kJ/kg, then cooling will be available. It will not be available otherwise.
- If the monthly average **dry-bulb temperature** is less than 15°C, heating will be available. It will not be available otherwise.



Heating availability is not dependent on enthalpy.

The above algorithm results in operating the systems for heating and cooling when the monthly average values fall outside the comfort range according to ISO 7730-1993. In some places like Mumbai, this algorithm will result in no difference between a seasonal availability and year-round availability, as the thresholds for turning off cooling or turning on heating will never be crossed.



Cooling Plant and/or **Heating Plant** are added depending on how an air system is configured.

Cooling Plant

Properties

Cooling System Inputs

System Name: Chiller Plant

Supply Water Temperature (°C): 6.7

Return Water Temperature (°C): 13

Chiller

Cooling Type: Water

Compressor Type: Centrifugal

Sizing: Autosize

Number of Chillers: 1

Chiller #1

Chiller Efficiency (COP): 5.8

Chiller Capacity (W):


OK Cancel

Specify the following properties (customizable inputs) of the cooling plant:

- Cooling System Inputs
- Chiller(s)
- Cooling Tower
- Primary Pump
- Secondary Pump
- Condenser Pump

Finally, click **OK** to define the cooling plant.

Heating Plant




Specify the following properties (customizable inputs) of the heating plant:

- Heating System Inputs
- Boiler
- Primary Pump
- Secondary Pump


Finally, click **OK** to define the heating plant.

9.1.3. Delete System

To delete a system, select it and click **Delete**. A confirmation dialog box appears.



Click **Yes** to delete the system. The system gets deleted.

 There is no way to undo this action and retrieve a deleted system.


9.2. Assignments

As per the ECBC, HVAC Zone is a space or group of spaces within a building with heating and cooling requirements that are sufficiently similar so that the desired conditions (for example, temperature) can be maintained throughout using a single sensor such as thermostat or temperature sensor.

A zone represents an area catered to by one air conditioning unit. With the help of zoning, building plans are simplified to reduce the modeller's work. Normally, usage pattern, set point temperature, and other conditions are identical within one zone. The building spaces that would experience similar heating and cooling loads are generally grouped under one zone.

ECONirman WBP Tool lists all the resulting zone types for each space type and allows assigning different HVAC systems to them individually or as a group for an entire space type. This allows the user to appropriately assign different HVAC systems to the perimeter zones and the core zones, and different HVAC systems to different perimeter zones.


This sub-tab is used to assign HVAC systems to different space types or zones.



The screenshot shows the ECO nirman software interface for Project: Centre 2. The 'HVAC' tab is selected, and the 'Space Type Assignment' table is displayed. The table has the following data:

Space Type	Area	Unconditioned	Central CAV	Central VAV
Enclosed Office	1303		<input checked="" type="radio"/>	<input type="radio"/>
Circulation	1153		<input checked="" type="radio"/>	<input type="radio"/>
Open Office	928		<input type="radio"/>	<input checked="" type="radio"/>
Mechanical Electrical Room	450	<input checked="" type="radio"/>		
Storage	376	<input checked="" type="radio"/>		
Medium Conference Room	301		<input checked="" type="radio"/>	<input type="radio"/>
Restrooms	150	<input checked="" type="radio"/>		
Lobby	150		<input checked="" type="radio"/>	<input type="radio"/>
Data Center	150		<input checked="" type="radio"/>	<input type="radio"/>
Large Conference Room	75		<input checked="" type="radio"/>	<input type="radio"/>

A combination of perimeter (by orientation) and core zones are created by the tool depending on the user inputs under the [Zoning](#) sub-tab (§ 7.2). Assign the system to the space type by selecting the corresponding radio button.

 Click ▶ adjacent to a space type to expand or collapse the tree structure in order to make HVAC system assignments at a detailed level by perimeter and orientation.

10. Conformance Check

ECONirman WBP Tool provides the conformance assessment result with a detailed report. The information in the report can be used for analysis and subsequent improvement of the building performance. This report can also be submitted to the *Authority Having Jurisdiction*.

Click the **Conformance Check** tab to respond to the mandatory requirements of the ECBC, run the simulation, and view the conformance results. The tab comprises of three sub-tabs on the left side that are explained in the following sub-sections.

10.1. Mandatory Requirements

This sub-tab is used to respond to the questions related to the mandatory requirements of the ECBC to assess a building's conformance.

Question	Answer
Envelope	
Fenestration	
U-Factor	
Is the U-factor for overall fenestration (including the sash and frame) determined in accordance with ISO- 15099, as specified in Appendix C §11, by an accredited independent laboratory, and labeled and certified by the manufacturer or other responsible party?	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA
Is the U-factor for sloped glazing and skylights determined at a slope of 20 degrees above the horizontal?	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA
Is the default table in Appendix C §11 used for determining the fenestration properties of unrated products?	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA
SHGC	
Is the SHGC determined for the overall fenestration product (including the sash and frame) in accordance with ISO-15099, as specified in Appendix C §11, by an accredited independent laboratory, and labeled and certified by the manufacturer or other responsible party?	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA
Air Leakage	
Is Air Leakage for glazed swinging entrance doors and revolving doors less than 5.0 l/sm ² ?	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA
Is Air Leakage for fenestration and doors other than glazed swinging entrance doors and	




The responses to **all** the mandatory requirements have to be either **Yes** or not applicable (**NA**) for the building to conform with the ECBC. The building will be non-conformant if the response to even one mandatory requirement is **No**.


10.2. Simulation

This sub-tab is used to run the simulation for the *Proposed Design* vis-à-vis the *Standard Design* to assess conformance of the building with the ECBC.


Click **Run** to initiate the simulation. A dialog box appears to save the project if there are unsaved changes.



Click **Yes** to save.

 It is imperative to save the project before running the simulation. Any unsaved project details under the tabs/sub-tabs will be otherwise lost.

The simulation starts.



The progress bar, time elapsed, status of the simulation, and issues encountered (if any) are displayed.

10.3. Results

This sub-tab is used to view the results of the simulation at the end of the run.

The screenshot shows the ECO nirman software interface. At the top, there is a logo for ECO nirman with the tagline 'Whole Building Performance'. Below the logo, the project name 'Project: Centre 2' is displayed. There are buttons for 'Save' and 'Return to Project List'. The main navigation menu includes tabs for 'Project Information', 'Building Use', 'Envelope', 'HVAC', and 'Conformance Check'. The 'Conformance Check' tab is selected, showing a table of results. The table has columns for 'Proposed Design', 'Standard Design', and 'Difference'. The results are as follows:


	Proposed Design	Standard Design	Difference
Number of hours any zone outside of throttling range	0	0	0
Number of hours any plant load not satisfied	0	0	0
10.3.2(e) of ECBC Satisfied?	Yes		
Annual Energy Use (kWh/yr)	2,887,036	2,805,992.75	+81,043.25
EPI (kWh/yr/m ²)	384.94	374.13	+10.81
Mandatory Requirements have been satisfied?	Yes		
Proposed EPI is less than or same as Standard?	No		
Building is in Conformance with the ECBC?	No		

At the bottom of the table, there is a 'Report' button.

10.3.1. Interpreting the Results

Meeting the Loads

Appendix B of the ECBC contains requirements in § 10.3.2 (e) for meeting the building loads through sizing of the systems and plants. The tool displays the results of the simulation vis-à-vis these requirements. The unmet load hours (**number of hours any zone outside of throttling range** and **number of hours any plant load not satisfied**) for the *Proposed Design* must not differ from unmet load hours for the *Standard Design* by more than 50 hours. And the maximum number of unmet hours must not exceed 300 hours for either case. If these conditions are met, then the design satisfies § 10.3.2 (e) of the ECBC. Whereas, if these conditions are not met, then the simulation results may not be submitted to the *Authority Having Jurisdiction* to demonstrate conformance; the inputs for sizing of the HVAC systems should be revised in the tool till § 10.3.2 (e) of the ECBC is satisfied.

 Depending on the inputs provided, it is possible in certain cases that the simulation results show that the hours when loads are not met by HVAC systems exceed those allowed in Appendix B of the ECBC. This is most likely to happen in the following situation:

When seasonal cooling availability for the building is selected, depending on the weather file, the tool turns off cooling for certain months of the year and changes the cooling set-points for those months to 50°C. However, the building may have a data centre with high internal loads. Therefore, during those months when cooling is not available, the data centre space may have a number of hours when the space temperature exceeds the cooling set-point. The tool will report those as hours when cooling load is not met. And if those hours exceed the limits allowed by Appendix B of the ECBC, the tool will report the building as non-conformant because a valid simulation has not been run.

To resolve this problem, make sure that such high load zones needing year-round cooling are on separate HVAC systems and that those systems are not selected for seasonal cooling availability. Then assign those zones or space types to separate HVAC systems under the [Assignments](#) sub-tab (§ 9.2). If the building does not have separate systems for such zones, then the simulation needs to run with cooling being always available to the building.

Energy Use and Energy Performance Intensity (EPI)

The energy use and the EPI of the *Proposed Design* must not exceed that of the *Standard Design*. Otherwise, the design will not conform with the ECBC.

10.3.2. Building Conformance Report

Click **Report** at the bottom of the **Results** sub-tab to generate a detailed Building Conformance Report as a Portable Document Format (PDF) file.



See [§ 12.2](#) to understand the settings required on the computer to access the conformance report.

The following is the composition of the building conformance report:

Report Section	Details Captured
Building Summary	Address, type, area, location, climate, ECBC conformance summary
Advisory Messages	Sizing results, errors, warnings
Building Use	Internal loads and thermal comfort settings (with schedules) for different space types
Building Envelope	Building envelope design inputs
HVAC Proposed Design Details	HVAC system inputs
HVAC Assignments	HVAC assignments to different space types
Mandatory Requirements	List of mandatory requirements with responses
Baseline Performance	Energy consumption by end-use for the <i>Standard Design</i>
Performance Rating Table	Energy consumption by end-use for the <i>Proposed Design</i> and the <i>Standard Design</i>
Energy Consumption	Energy consumption by energy fuel type for the <i>Proposed Design</i> and the <i>Standard Design</i>

11. Appendix A: Definitions and Acronyms

11.1. Definitions

The following are certain relevant definitions from the ECBC 2007.

Boiler: a self-contained low-pressure appliance for supplying steam or hot water.


Building envelope: the exterior plus the semi-exterior portions of a building.

Coefficient Of Performance (COP) – cooling: the ratio of the rate of heat removal to the rate of energy input, in consistent units, for a complete refrigerating system or some specific portion of that system under designated operating conditions.


Coefficient Of Performance (COP) – heating: the ratio of the rate of heat delivered to the rate of energy input, in consistent units, for a complete heat pump system, including the compressor and, if applicable, auxiliary heat, under designated operating conditions.

Daylighted area: the daylight illuminated floor area under horizontal fenestration (skylight) or adjacent to vertical fenestration (window), described as follows:

- **Horizontal Fenestration:** the area under a skylight, monitor, or sawtooth configuration with an effective aperture greater than 0.001 (0.1%). The daylighted area is calculated as the horizontal dimension in each direction equal to the top aperture dimension in that direction plus either the floor-to-ceiling height (H) for skylights, or 1.5 H for monitors, or H or 2H for the sawtooth configuration, or the distance to the nearest 1000 mm (42 in) or higher opaque partition, or one-half the distance to an adjacent skylight or vertical glazing, whichever is least, as shown in the plan and section figures below.



- Vertical Fenestration:** the floor area adjacent to side apertures (vertical fenestration in walls) with an effective aperture greater than 0.06 (6%). The daylighted area extends into the space perpendicular to the side aperture a distance either two times the head height of the side aperture or to the nearest 1.35 m (54 in) or higher opaque partition, whichever is less. In the direction parallel to the window, the daylighted area extends a horizontal dimension equal to the width of the window plus either 1 m (3.3 ft) on each side of the aperture, the distance to an opaque partition, or one-half the distance to an adjacent skylight or window, whichever is least.



Economizer, air: a duct and damper arrangement and automatic control system that together allow a cooling system to supply outdoor air to reduce or eliminate the need for mechanical cooling during mild or cold weather.

Economizer, water: a system by which the supply air of a cooling system is cooled indirectly with water that is itself cooled by heat or mass transfer to the environment without the use of mechanical cooling.

Fenestration: all areas (including the frames) in the building envelope that let in light, including windows, plastic panels, clerestories, skylights, glass doors that are more than one-half glass, and glass block walls.

- **Skylight:** a fenestration surface having a slope of less than 60 degrees from the horizontal plane. Other fenestration, even if mounted on the roof of a building, is considered vertical fenestration.
- **Vertical fenestration:** all fenestration other than skylights. Trombe wall assemblies, where glazing is installed within 300 mm (12 in) of a mass wall, are considered walls, not fenestration.

Fenestration area: total area of the fenestration measured using the rough opening and including the glazing, sash, and frame. For doors where the glazed vision area is less than 50% of the door area, the fenestration area is the glazed vision area. For all other doors, the fenestration area is the door area.

HVAC system: the equipment, distribution systems, and terminals that provide, either collectively or individually, the processes of heating, ventilation, or air conditioning to a building or portion of it.

Kilovolt-ampere: where the term “kilovolt-ampere” (kVA) is used in this standard, it is the product of the line current (amperes) times the nominal system voltage (kilovolts) times 1.732 for three-phase currents. For single-phase applications, kVA is the product of the line current (amperes) times the nominal system voltage (kilovolts).

Kilowatt: the basic unit of electric power, equal to 1000 W.

Lighted floor area, gross: the gross floor area of lighted spaces.

Lighting Power Density: the maximum lighting power per unit of area of a building classification of space function.

Packaged Terminal Air Conditioner: a factory-selected wall sleeve and separate unencased combination of heating and cooling components, assemblies, or sections. It may include heating capability by hot water, steam, or electricity, and is intended for mounting through the wall to service a single room or zone.

Process load: the load on a building resulting from the consumption or release of process energy.

R-value (thermal resistance): the reciprocal of the time rate of heat flow through a unit area induced by a unit temperature difference between two defined surfaces of material or construction under steady-state conditions. Units of R are $m^2\text{-}^\circ\text{C/W}$ ($\text{h}\text{-ft}^2\text{-}^\circ\text{F/Btu}$). For the prescriptive building envelope option, R-value is for the insulation alone and does not include building materials or air films.

Roof: the upper portion of the building envelope, including opaque areas and fenestration, which is horizontal or tilted at an angle of less than 60° from horizontal.

Roof area, gross: the area of the roof measured from the exterior faces of walls or from the centerline of party walls.

Single-zone system: HVAC system serving a single HVAC zone.

Skylight roof ratio (SRR): the ratio of the total skylight area of the roof, measured to the outside of the frame, to the gross exterior roof.

Solar Heat Gain Coefficient: the ratio of the solar heat gain entering the space through the fenestration area to the incident solar radiation. Solar heat gain includes

directly transmitted solar heat and absorbed solar radiation, which is then reradiated, conducted, or convected into the space.

Standard Design: A computer representation of a hypothetical design based on the actual proposed design as per Appendix B of the ECBC.

Thermal block: a collection of one or more HVAC zones grouped together for simulation purposes. Spaces need not be contiguous to be combined within a single thermal block.


U-factor (Thermal Transmittance): heat transmission in unit time through unit area of a material or construction and the boundary air films, induced by unit temperature difference between the environments on each side. Units of U are $W/m^2\text{-}^\circ C$ ($Btu/h\text{-ft}^2\text{-}^\circ F$).

Variable Air Volume system: HVAC system that controls the dry-bulb temperature within a space by varying the volumetric flow of heated or cooled supply air to the space.

Wall: portion of the building envelope, including opaque area and fenestration that is vertical or tilted at an angle of 60° from horizontal or greater. This includes above-grade and below-grade walls, between floor spandrels, peripheral edges of floors, and foundation walls.

- **wall, below grade:** that portion of a wall in the building envelope that is entirely below the finish grade and in contact with the ground
- **wall, above grade:** a wall that is not below grade

Wall area, gross: the overall area off a wall including openings such as windows and doors, measured horizontally from outside surface to outside service and measured vertically from the top of the floor to the top of the roof. If roof insulation is installed at the ceiling level rather than the roof, then the vertical measurement is made to the top of the ceiling. (Note that ECBC Section 4.3.1 does not allow roof insulation to be located on a suspended ceiling with removable ceiling panels.) The gross wall area includes the area between the ceiling and the floor for multi-story buildings.



Window Wall Ratio: the ratio of vertical fenestration area to gross exterior wall area. Gross exterior wall area is measured horizontally from the exterior surface; it is measured vertically from the top of the floor to the bottom of the roof.

Zone, HVAC: a space or group of spaces within a building with heating and cooling requirements those are sufficiently similar so that the desired conditions (for example, temperature) can be maintained throughout using a single sensor such as thermostat or temperature sensor.

11.2. List of Acronyms

The following is the list of relevant acronyms.

AC	Air Conditioner
AFUE	Annual fuel utilization efficiency
AHU	Air Handling Unit
ANSI	American National Standards Institute
ARI	Air-Conditioning and Refrigeration Institute
ASHRAE	American Society of Heating, Refrigerating and Air-Conditioning Engineers
ASTM	American Society for Testing and Materials
BEE	Bureau of Energy Efficiency
BIS	Bureau of Indian Standards
Btu	British thermal unit
Btu/ft ² °F	British thermal units per square foot per degree Fahrenheit
Btu/h	British thermal units per hour
Btu/h ft °F	British thermal units per lineal foot per degree Fahrenheit
Btu/h ft ²	British thermal units per hour per square foot
Btu/h ft ² °F	British thermal units per hour per square foot per degree Fahrenheit
C	Celsius
CAV	Constant Air Volume
cfm	Cubic feet per minute
cm	Centimeter
COP	Coefficient of Performance
DG/GG	Diesel Generator/Gas Generator
DX	Direct expansion
EC Act 2001	Energy Conservation Act 2001
ECBC	Energy Conservation Building Code
ECM	Energy Conservation Measure
ECO-III	Energy Conservation and Commercialization - Phase III
EER	Energy Efficiency Ratio
EF	Energy Factor
EPI	Energy Performance Intensity
F	Fahrenheit
ft	Foot
GIS	Geospatial Information System
h	Hour

h·ft ² ·°F/Btu	Hour per square foot per degree Fahrenheit per British thermal unit
h·m ² ·°C/W	Hour per square meter per degree Celsius per Watt
HC	Heat capacity
hp	Horsepower
HSD	High Speed Diesel
HSPF	Heating seasonal performance factor
HVAC	Heating, Ventilation and Air Conditioning
in.	Inch
I-P	Inch-pound
IPLV	Integrated part-load value
IRG	International Resources Group
ISHRAE	Indian Society of Heating, Refrigeration and Air-conditioning Engineers
ISO	International Organization for Standardization
kVA	kilovolt-ampere
kW	kilowatt
kWh	kilowatt-hour
l/s	litre/second
LE	Lighting efficacy
lin	Linear
lin ft	Linear foot
lin m	Linear meter
lm	Lumen
LPD	Lighting Power Density
m	Meter
m ²	Square meter
mm	Millimeter
NAECA	National Appliance Energy Conservation Act
PDF	Portable Document Format
PF	Projection factor
PSZ	Packaged Single Zone
PTAC	Packaged Terminal Air Conditioner
R	R-value (thermal resistance)
RHFS	Reheat Fan System
Rs.	Indian Rupees
SC	Shading Coefficient
SHGC	Solar Heat Gain Coefficient
SHWP	Service Hot Water and Pumping
SL	Standby loss

SRR	Skylight roof ratio
TR	Tons of Refrigeration
TWGI	The Weidt Group, Inc.
ULB	Urban Local Body
USAID	United States Agency for International Development
VAV	Variable Air Volume
VLT	Visible Light Transmission
W	Watt
W/ft ²	Watts per square feet
W/m °C	Watts per lineal meter per degree Celsius
W/m ²	Watts per square meter
W/m ² °C	Watts per square meter per degree Celsius
Wh	Watt-hour
WRR	Window Wall Ratio



12. Appendix B: Computer Settings

ECONirman WBP Tool is a web based rich Internet application (RIA) that has characteristics of a desktop application. It runs on a standard web browser and communicates with a web service, where the building model is built in the cloud (Internet). The energy simulation also runs in the cloud using the DOE2.1E engine. As a result, no special software needs to be installed on the computer. Additionally, the following are updated automatically:


- Tool features
- Default inputs in the tool
- Energy modelling protocols
- The ECBC revisions impacting the simulation

Unlike traditional applications, the tool runs much faster without using much connectivity bandwidth as a result of minimal data exchange with the servers.

The following are the system settings and recommendations to use the tool:

- Microsoft® Silverlight™ should be installed on the computer.
 Silverlight™ can be downloaded free of cost from www.silverlight.net 
(consult the System Administrator for assistance, if required).
- No other plug-in or simulation software is required to use the tool.
- The tool is best viewed in 1024x768 or higher screen resolution.
- For security reasons, logout of the tool after each session.


12.1. Web Browser

- ECONirman WBP Tool works with all the popular web browsers. It is recommended to use the latest versions of the web browsers for an optimal experience.
- It takes some time for the tool to load in the web browser for the first time. The loading time reduces subsequently.
- JavaScript must be enabled in the web browser.
- The web browser must be set to accept cookies.
- If the web browser has a provision, add <http://econirmanwbp.eetools.in>  as a trusted site.

12.2. Conformance Reports

- All conformance reports are generated as Portable Document Format (PDF) files. Therefore, Adobe® Reader® (version 6.0 or higher) must be installed on the computer to view these reports.



Adobe® Reader® can be downloaded free of cost from <http://get.adobe.com/reader>  (consult the System Administrator for assistance, if required).

- A conformance report opens in a different pop-up window.
 - It is imperative to allow the pop-ups to open in the web browser. The report will not open if the pop-ups are blocked. Pop-up settings in the third-party toolbar (if installed) also need to be changed accordingly.
 - Wait for the report to open. Do not immediately close the new window that pops-up.



USAID ECO-III Project

AADI Building, (Lower Ground Floor)
2 Balbir Saxena Marg, Hauz Khas, New Delhi - 110 016
Tel: +91-11-4597 4597; Fax: +91-11-2685 3114
Email: eco3@irgssa.com; Website: www.eco3.org